



SERVICE MANUAL

DVD-909/709



## DVD PLAYER

DVD-909

DVD-709

# SERVICE Manual

### DVD PLAYER



DVD-909



DVD-709


### CONTENTS

1. Precautions
2. Reference Information
3. Product Specification
4. Operating Instructions
5. Disassembly and Reassembly
6. Circuit Descriptions
7. Troubleshooting
8. Exploded Views and Parts List
9. Electrical Parts List
10. Block Diagrams
11. PCB Diagrams
12. Wiring Diagram
13. Schematic Diagrams


# 13. Schematic Diagrams

13-1 S.M.P.S. - - - - -	13-2
13-2 Main Power Supply - - - - -	13-3
13-3 Main Micom - - - - -	13-4
13-4 Servo - - - - -	13-5
13-5 Video - - - - -	13-6
13-6 Audio- - - - -	13-7
13-7 5.1 Channel Audio (DVD-909 Only) - - - - -	13-8
13-8 RF - - - - -	13-9
13-9 ZiVA - - - - -	13-10
13-10 DSP - - - - -	13-11
13-11 Front Micom/VFD Display - - - - -	13-12
13-12 Component (DVD-909 NTSC Only) - - - - -	13-13
13-13 Scart Jack (DVD-909 PAL Only) - - - - -	13-14
13-14 Mute - - - - -	13-15
13-15 Play & Phone/Power (DVD-909 Only) - - - - -	13-16
13-16 Play & Power (DVD-709 Only) - - - - -	13-16
13-17 Deck - - - - -	13-17
13-18 Remote Control - - - - -	13-18

Block Identification of PCB




Main PCB (Component Side)



Jack PCB (Conductor Side)




13-2 Main Power Supply






## 13-4 Servo






## 13-6 Audio






13-7 5.1 Channel Audio (DVD-909 Only)




## 13-8 RF







### 13-10 DSP











## 13-14 Mute







13-15 Play & Phone/Power (DVD-909 Only)



13-16 Play & Power (DVD-709 Only)



13-17 Deck



13-18 Remote Control

